



DUAL CHANNEL RF FREQUENCY WIRELESS MICROPHONES

TMS304-BK



Operating Guide



WIRED PROFESSIONAL MICROPHONE

TMS304-BK

Thank you for purchasing a Tyler product! Please take a moment to read through this operating guide to ensure proper setup and function of this device and to avoid possible malfunction and/or damage. Please note that the warranty does not include coverage for damage caused by improper or unsafe use.

OPERATING INSTRUCTIONS

CONNECTING AND USING THE MICROPHONE:

1. Uncoil microphone audio cable. Plug audio cable jack into the input on the bottom of the microphone, making sure to line up the plug correctly to match the orientation of the jack. If the cable jack does not seem to fit, DO NOT FORCE THE PLUG. Examine connection again, making sure that the connectors line up.
2. Make sure that the microphone power switch is set to the OFF position. Plug the audio cable into the MICROPHONE/INPUT of receiver, mixer or amplifier. Turn volume of amplifier down to its minimum level, and switch the microphone power switch to the ON position. Increase the volume level of the amplifier channel until desired volume is reached.

TECHNICAL SPECIFICATIONS

Frequency Response: 50Hz-16KHz
Unit weight: 20g
Pickup pattern: Cardioid
Sensitivity: -54dB±3dB(0dB=1V/par at 1 KHz)
Impedance: 600Ω±30% at 1KHz

SAFETY INSTRUCTIONS

READ INSTRUCTIONS: Read all safety and operating instructions prior to use.

RETAIN INSTRUCTIONS: The safety and operating instructions should be saved for future reference

FOLLOW INSTRUCTIONS: All operating and safety instructions should be followed.

CLEANING: Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a dry cloth to clean.

WATER AND MOISTURE: To avoid electrocution risk, do not use this product near water.

STABILITY: Do not place this product on an unstable cart, stand, bracket or table. The product may fall, causing serious injury to a child or adult, and/or may damage product.

AUDIO CABLE PROTECTION: Audio cables should be routed so that they are not likely to be walked on, tripped over, or pinched by items placed on or against them, and paying particular attention to the points where the cable meets the output device and where the cable leaves the microphone.

PRODUCT SERVICE: Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all service to a qualified technician.



LIMITED WARRANTY

Tyler provides a Limited Warranty of ONE YEAR for all of its products. Tyler warrants this product to the original purchaser ONLY, to be free from defects in materials and workmanship originating from the manufacturer. Tyler agrees, at its discretion during the warranty period, to repair or replace the product if it is determined to be defective at "no charge". This warranty does not cover cosmetic damage, antennas, AC cords, damage due to power surges, connection to improper voltage supplies, damage caused by leaking batteries, misuse, mishandling, improper application, acts of God, or attempted repair by an unauthorized service agent. Products are sold for personal, non-commercial use only. Product is not warranted for commercial or rental use.

In order to have your merchandise repaired or replaced under warranty, you must contact Tyler's customer service department at the number or email address below **within the warranty period**. The customer service department will provide you with an RMA number (return authorization code) and the street address for product service/returns. With the product, **you must include the following**:

1. **Proof of purchase**, which must have a purchase date which falls within the warranty period specified in the product manual.
2. **All of the items and accessories that came in the package**, as well as the main unit.
3. **A detailed description of the problem you are having with the product.**
4. All returns must have an **RMA Number** (an RMA number can be obtained by contacting customer service).

The product must be sent in the original packaging, or a reasonable substitute, to prevent damage. You must include your full name, shipping address, and telephone number for order reference. No return will ship back to a PO Box.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. TYLER SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT.

The warranty period of a repaired or replaced unit will be the balance of the original purchase date.